


USER MANUAL WIRELESS MOTION SENSOR



1. Place 2 AAA batteries in the battery compartment, take note of the - and + on the battery compartment.





Connect with the ERIA hub

2A. Download the Adurosmart App from the Apple App Store or from Google Play or go to http://adurosmart.com/adurosmart-app/





2B. If you have a third party ZigBee compatible hub then proceed to step 9.

Open the AduroSmart ERIA App. 4. On the bottom right corner press on "Settings".



... HOME LIGHTS Notification settings Voice Assistants

5. Select "Devices"

6. On the top right corner press on the "+" symbol




7. Press on "Brands" and then select "AduroSmart ERIA".



8. Press on "Motion Sensor"




9. Locate the small pinhole button on the sensor, use a small pin or paperclip to press the button for seconds, the LED indicator will flash continuously for 60 seconds indicating that the sensor is in pairing mode. Press on "Search" to start searching for the sensor. During the pairing mode the LED indicator on the sensor will flash green slowly for 60 seconds.



9B. If you have a third party hub, then this is the moment to initiate the search from your Smart Home hub app

10. Proceed by pressing on "Search" to allow the Adurosmart ERIA hub to find the sensor, the LED indicator on the hub will flash green this indicates that the hub is searching for new devices.



11. When the sensor has been found and paired successfully the sensor will stop flashing and it will show up in your search results, press on "Done" to complete the process.




12. Troubleshoot

If you are experiencing issues while connecting the Sensor then please follow below instructions to reset the sensor.

Coming home

0

Locate the small pinhole button on the sensor, use a small pin or paperclip to press the button for 10 seconds the sensor LED indicator will flash quickly to confirm the reset.



Connection mode LED will flash once per second for approximately 1 min. Connection successfully LED will stop flash. Sensor reset LED will flash fast. Sensor triggered LED will flash once quickly. When sensor is triggered within the object or person in 10 meters

NEED HELP? CALL US

For troubleshoots, instruction video's or more information please visit us at www.adurosmart.com/faq

> Chat with one of our support agents at www.adurosmart.com

The Netherlands: +31 523687532 support@adurosmart.eu



www.adurosmart.com/manuals/motionsensor